


VIZIO



QUICK START GUIDE

Model: SP50-D5

IMPORTANT SAFETY INSTRUCTIONS

Your Unit is designed and manufactured to operate within defined design limits, and misuse may result in electric shock or fire. To prevent your Unit from being damaged, the following rules should be observed for its installation, use, and maintenance. Please read the following safety instructions before operating your Unit. Keep these instructions in a safe place for future reference.

- CAUTION: Please read the entire user manual carefully before using this product.
- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not expose the battery to fire. Do not throw or place the battery into a fire.
- Never reverse charge the battery.
- Never short circuit the battery.
- Avoid excessive physical shock or vibration.
- Do not disassemble or deform the battery.
- Never allow the battery to get wet or be immersed in water.
- Do not use non-Lithium Ion batteries of a different type or capacity with this product.
- Keep away from children.
- Charge at the appropriate conditions.
- Only use the charging dock provided to charge this product. All other means of charging this product is prohibited.
- Never charge the battery for more than 24 hours at a time
- Do not use this unit near water.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other unit (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the unit.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the unit. When a cart is used, use caution when moving the cart/unit combination to avoid injury from tip-over.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the unit, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped. Maintain an open space for all sides of the system for ventilation purposes.
- To reduce the risk of electric shock or component damage, switch off the power before connecting other components to your Unit.
- Unplug the power cord before cleaning your Unit. A damp cloth is sufficient for cleaning. Do not use a liquid or a spray cleaner on your Unit. Do not use abrasive cleaners.

- Always use the accessories recommended by the manufacturer to insure compatibility.
- When moving your unit from an area of low temperature to an area of high temperature, condensation may form in the housing. Wait before turning on your unit to avoid causing fire, electric shock, or component damage.
- To ensure reliable operation of your unit and to protect it from overheating, be sure any openings are not blocked or covered. Do not place your Unit in a bookcase or cabinet unless proper ventilation is provided.
- Never push any object into the slots and openings on your unit enclosure. Do not place any objects on the top of your unit. Doing so could short circuit parts causing a fire or electric shock. Never spill liquids on your unit.
- **WARNING:** Exposure to loud sounds can damage your hearing causing hearing loss and tinnitus (ringing or buzzing in the ears). With continued exposure to loud noises, ears may become accustomed to the sound level, which may result in permanent damage to hearing without any noticeable discomfort.
- When connected to a power outlet, power is always flowing into your unit. To totally disconnect power, unplug the power cord.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- The wall socket should be located near your Unit and be easily accessible
- Keep your unit away from moisture. Do not expose your Unit to rain or moisture. If water penetrates into your unit, unplug the power cord and contact your dealer. Continuous use in this case may result in fire or electric shock.
- Do not use your unit if any abnormality occurs. If any smoke or odor becomes apparent, unplug the power cord and contact your dealer immediately. Do not try to repair your unit yourself.
- Avoid using dropped or damaged appliances. If your unit is dropped and the housing is damaged, the internal components may function abnormally. Unplug the power cord immediately and contact your dealer for repair. Continued use of your unit may cause fire or electric shock.
- Do not install your unit in an area with heavy dust or high humidity. Operating your unit in environments with heavy dust or high humidity may cause fire or electric shock.
- Ensure that the power cord and any other cables are unplugged before moving your charging unit.
- When unplugging your unit, hold the power plug, not the cord. Pulling on the power cord may damage the wires inside the cord and cause fire or electric shock. When your unit will not be used for an extended period of time, unplug the power cord.
- To reduce risk of electric shock, do not touch the connector with wet hands.
- See the important note and rating located on the back of the unit.
- **WARNING -** This unit is not waterproof. To prevent a fire or shock hazard, do not place any container filled with liquid near the equipment (such as a vase or flower pot) or expose it to dripping, splashing, rain, or moisture.
- The unit shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the unit.
- Where the MAINS plug or appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- **WARNING:** to reduce the risk of fire or electric shock, do not expose the speaker or charging unit to rain or moisture.

WARNING: To reduce the risk of fire or electric shock, do not expose this unit to rain or moisture.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of not isolated dangerous voltage within the product that may be sufficient magnitude to constitute a risk of shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying the appliance.



Warning: This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

TABLE OF CONTENTS

Package Contents.....	5
Welcome to VIZIO SmartCast™!	7
Controls & Connections.....	8
LED Indicators.....	10
Charging the Speaker.....	11
Turning the Speaker on/Off.....	12
Using Your Tablet or Smartphone as a Remote	13
Minimum Recommended Requirements.....	13
First-Time Setup.....	14
Pairing Via Wi-Fi.....	18
Getting started with Google Cast™	19
How to cast content.....	19
Selecting a SmartCast device	20
Creating an Audio Group.....	21
Bluetooth Pairing.....	22
Using Bluetooth Mode.....	23
Help & Troubleshooting.....	26
Limited Warranty.....	27
Legal & Compliance.....	30

PACKAGE CONTENTS



VIZIO SmartCast Crave 360 Speaker



Charging Station
(Power Cable Attached)



Quick Start Guide




Welcome to VIZIO SmartCast™!

Your new VIZIO SmartCast Crave 360 Speaker is part of the all-new collection of home theater displays, sound bars and home audio speakers that can all be controlled by one ingenious app: the VIZIO SmartCast app.


With the app, you can browse online radio, music and more from multiple sources or apps in one view, without having to switch back and forth between those apps or sources. And then just tap to cast the content to your VIZIO Speaker - from anywhere in your home. It works over WiFi, so you can control your VIZIO Speaker from any room, and keep using your smartphone or tablet to continue browsing, play games, text or even watch another show, without disrupting what's playing on your speaker. With VIZIO SmartCast, what you love doesn't change, but how you experience it will never be the same.

Now let's get you into setup so you can start casting!

CONTROLS & CONNECTIONS




Front of Speaker



Back of Speaker

* Supports .WAV file format playback only.

Single Tap: Play/Pause Content



Swipe Right: Skip to Next Track*



Spin Volume Ring Left/Right:
Increase or Decrease Volume












* Skip controls based on app support.

A quick spin increases/decreases volume at a faster rate.
A slow spin increases/decreases volume at a slower rate for fine-tuning.



LED INDICATORS

LED Behavior	Description
Off 	Speaker is off.*
Rapid pulsing white 	Speaker is starting up.
Pulsing white 	Speaker is ready to be setup via the SmartCast App or connecting to a previous network.
Solid white 	Speaker is connected to a network and ready to Cast.
Pulsing blue 	Speaker is in bluetooth discovery mode.
Solid blue 	Speaker is bluetooth connected to device and ready to play audio.
Pulsing red 	Error has occurred.
Red 	Speaker battery is low. (see page 11 for more)
Very rapid pulsing white 	Speaker is installing an update.

*Note: when removed from the charging station, the speaker will power off after a period of inactivity in order to preserve battery life. In this event, the power button on your device remote must be pressed to power on the speaker.

CHARGING THE SPEAKER

The Crave 360 Speaker offers up to **8 hours** of playback time on a full charge.

To charge your speaker:

- Plug the charging station into an outlet
- Place the Crave 360 speaker onto the charging station

It takes 3.5 hours to fully charge the speaker.



If removed from the charging station, the speaker will enter standby mode after 5 minutes of inactivity.

When the speaker battery falls below 20%:

- If streaming, the speaker will beep and the LED will glow red.
- If in standby, the LED will glow red.



TURNING THE SPEAKER ON/OFF

To turn the speaker on :

- Press the back LED button.

The LED will rapidly pulse white as it starts up.



To turn the speaker off:

- Short press the back LED button.

The LED button will turn off when powered down.



*If the speaker is docked, you can wake it by:

- Pressing power on the SmartCast App.
- Pressing the back LED button.



If the speaker powers off when not docked, the LED button must be pressed to power it back on.


To reset your speaker:

- Using a paper clip, press the bottom pinhole to reset.

A short press resets the battery connection.

A long press of 20 seconds, holding until after the LED button stops flashing, will factory reset the speaker.

You can also reset the speaker via the app settings.



*Docked speaker can be turned on by initiating a new cast session if Eco Power Mode is disabled.

USING YOUR TABLET OR SMARTPHONE AS A REMOTE

Download the VIZIO SmartCast app and turn your smartphone or tablet into a remote to control your speaker. Easily search, discover and browse for content to listen through your speakers.

To use your smartphone or tablet as your VIZIO SmartCast Remote:

- Download the VIZIO SmartCast app on your compatible smartphone or tablet and follow the on-screen instructions to pair your device with a VIZIO SmartCast Speaker.

Minimum Recommended Requirements.

Android™*

- Android 4.4 or higher**
- RAM: 1.5GB or more
- Storage: 8GB or more
- Networking: Wi-Fi

For a list of supported devices, see Google Play™ supported device article. †


iOS*

- iOS 8.0 or later
- Devices supported: iPhone, iPad

*Subject to change


**To use the Bluetooth LE functionality you must have Android 5.1 or later

†<https://support.google.com/googleplay/answer/1727131>




FIRST-TIME SETUP

1



Download and launch the VIZIO SmartCast app.

2



Tap the **Create an Account** button to sign up for a MyVIZIO account.

OR

If you already have an account, tap **Sign In** below the **Create an Account** button to log into your account

3



Plug the charging station's power cable into an electrical outlet.

4



Place the speaker on the charging station.





Do not immerse or expose the charging base to water.

5

Press the power button on the back of the speaker to power it on. The LED will rapidly pulse white when starting up.


6

From the VIZIO SmartCast app, tap on the  button in the top left corner. The side menu is displayed.



7

Tap  **Setup a new Device** from the list of options. The setup wizard appears and begins the pairing process





8

Hold your smartphone or tablet close to the VIZIO logo on the front of the speaker for at least 5 seconds to pair it with the speaker.

Follow the remaining on-screen instructions on your smartphone or tablet to finish the setup wizard.

A tone will confirm successful pairing.



VIZIO SmartCast App required for Wi-Fi setup. Setup is required for every new Wi-Fi network.



Bluetooth mode is recommended when outside of Wi-Fi range.



Pairing Via Wi-Fi

If your device is not bluetooth enabled or you are having trouble pairing, connect to your speaker through the local Wi-Fi network.

To pair through a Wi-Fi network:

1. Tap **Connect Via Wi-Fi** from the SmartCast App's pairing screen
2. Look for your speakers name on the list of discovered devices and tap to select.

Follow the on screen instructions to finish the setup wizard.



Your speaker name is displayed on the screen during the setup process. Look for a name such as *VIZIOCastAudio1234*.







GETTING STARTED WITH GOOGLE CAST™

Google Cast™ allows you to wirelessly send, or cast, music from your smartphone or tablet to your SmartCast Speaker.

How to cast content

To cast music to your speaker

1. Open any Cast-enabled app. Visit g.co/cast/audioapps for a list of compatible apps.
2. Select the content you'd like to hear and tap the Cast icon  on the app screen.
3. Select the device you'd like to cast to and press play. Turn up the volume and control the speaker right from your phone or tablet.




Selecting a SmartCast device

You can pair your smartphone or tablet with multiple SmartCast devices, allowing you to seamlessly access and cast your content wherever you are.

To select a different SmartCast device:


1. On the Home screen of the Vizio SmartCast app, tap **This Device** to reveal a list of available devices.
2. Tap to select a new device to control. Make sure the newly selected SmartCast device is turned on.




CREATING AN AUDIO GROUP

With Google Cast's multi-room playback capability, you can create audio groups and cast different music or the same music to multiple speakers at the same time. Prior to creating an audio group, make sure all speakers and sound bars have been set up using the VIZIO SmartCast App.

To create an audio group:

1. Install and open the Google Chromecast app.
2. Tap Devices to see a list of available audio devices and select a device. Tap the  menu icon on the top right corner of the speaker window.
3. From the menu, select Create group. A list of all available speakers appears.
4. Check or uncheck the box next to each speaker to add or remove it from the group. Tap save to finalize the group.*

*Only audio devices can be put into groups.



BLUETOOTH PAIRING

*To pair the speaker with a Bluetooth device:

1. If the speaker is off, power it on by pressing the back LED button. Wait for the LED to be solid white or pulsing white.
2. Press and hold the LED button on the back of the speaker for five (5) seconds. When the speaker is in Bluetooth Pairing Mode, the LED will pulse blue and a pairing tone will be heard.
3. You can now search for the speaker (SP50-D5) using your Bluetooth device. For more information, refer to the user documentation that came with the device.

Once the device is paired, the LED button will stop pulsing and remain a solid blue .

4. Play audio from your Bluetooth device. Volume can be controlled on your source device and the speaker.

To exit Bluetooth Mode and return to Cast Mode:

1. Select the speaker on the SmartCast App and begin a new cast session. See "Getting started with Google Cast™" on page 19.
2. Select the speaker on the SmartCast App and setup a new Wi-Fi connection.
3. Disable the Bluetooth connection from the source device.

*To switch bluetooth devices, the connected device must disconnect before the new device can connect.



Back of Speaker



Bluetooth Device

USING BLUETOOTH MODE

Your speaker supports music streaming from smartphones, tablets, and computers with Bluetooth capability. Device compatibility will vary, see your device's documentation for more information. Once you have paired your source device to the speaker, as long as you stay within range of the speaker, your device should remain paired. If the input is changed, the Bluetooth device will disconnect. If the source is changed back to Bluetooth, any paired Bluetooth device will reconnect automatically.



Your speaker is not equipped with a microphone, so it cannot operate as a hands-free device for a smartphone.

Maximizing Signal

A Bluetooth signal has a range of up to 30 feet. Keep in mind that Bluetooth is a compressed audio format, so streamed music may lose some integrity when compared to a wired connection.

Try the following if your sound quality is less than optimal:

- If you hear any break-up or disconnect while streaming music from your device, move the source device closer to the speaker.
- Be sure that there are no solid obstructions in the line-of-sight between the speaker and the source device.
- Other wireless devices can affect Bluetooth range, including wireless security cameras, wireless video baby monitors, cordless phones, and microwave ovens. Turning off or moving these devices may improve Bluetooth range.



Reduce the volume levels on your device and on the speaker before pressing Play. High volume levels can damage your hearing.



VIZIO.COM/PRODUCT-REGISTRATION

Why register?



Customized Support

Get assistance quickly with your information on hand.



News and Offers

Take advantage of the latest news and special offers from VIZIO.



Safety and Satisfaction

Stay up-to-date with important product updates and notifications.



NEED HELP?

Go to: support.vizio.com

Find help with:

- New product setup
- Connecting your devices
- Technical problems
- Product updates and more



Live chat
support available

You can also contact our
popular support team at:

Phone: (877) 698-4946 (toll-free)

Hours of Operation:

Monday - Friday: 7 AM TO 11 PM (CST)
Saturday - Sunday: 9 AM TO 6 PM (CST)

Se habla Español • Nous parlons Français



HELP & TROUBLESHOOTING

There is no power.

- Return the speaker to the charging station and press the **POWER** LED button on the back of the speaker.
 - Plug a different device into the electrical outlet to verify that the outlet is working correctly.
-

There is no sound.

- Increase the volume. Press **Volume Up** on your smartphone or tablet remote or turn the volume ring clockwise to increase the speaker volume
 - If using Bluetooth, ensure that the volume on your source device is turned up and that the device is not muted.
 - Ensure the speaker is properly paired with the cast source device.
 - Tap the Play/Pause sensor on the top of the speaker.
 - If the speaker is out of Wi-Fi range, move the speaker closer to the access point used during setup or switch to bluetooth mode for streaming audio.
-

Smartphone/ tablet remote app isn't working.

- Ensure the device is properly paired with the speaker. See *First-Time Setup* section.
 - Ensure the speaker is selected within the SmartCast App. See *Selecting a SmartCast Device*.
-

LED button is pulsing red.

- Reconnect to Wi-Fi following the steps in the *First-Time Setup* section.
- Using a paper clip, press the bottom pinhole to reset. A short press resets the battery connection. A long press of 20 seconds, holding until after the LED button stops flashing, will factory reset the speaker. After a factory reset, the speaker will need to be set up once more. See *First-Time Setup* section.

LIMITED WARRANTY

UNITED STATES AND CANADA

BY USING YOUR VIZIO PRODUCT YOU AGREE TO BE BOUND BY ALL THE TERMS OF THIS WARRANTY. BEFORE USING YOUR VIZIO PRODUCT, PLEASE READ THIS WARRANTY CAREFULLY. IF YOU DO NOT AGREE TO THE TERMS OF THIS WARRANTY, DO NOT USE THE VIZIO PRODUCT AND, WITHIN THIRTY (30) DAYS OF THE DATE OF PURCHASE, RETURN IT FOR A REFUND TO THE AUTHORIZED RETAILER WHERE YOU PURCHASED IT.

This warranty contains a binding arbitration agreement and a class action waiver for United States residents. If you live in the United States, the binding arbitration agreement and class action waiver affect your rights under this warranty. Please read the text under the section titled "Binding Arbitration Agreement; Class Action Waiver (U.S. Residents Only)" carefully.

How Long This Warranty Lasts

For non-commercial use, VIZIO warrants the product on the terms set forth below for one (1) year from the date of original purchase. For commercial use, VIZIO warrants this product on the terms set forth below for ninety (90) days from the date of original purchase.

What This Warranty Covers

VIZIO warrants the product against defects in materials and workmanship when the product is used normally in accordance with VIZIO's user guides and manuals.

Except where restricted by law, this warranty applies only to the original purchaser of a new product. The purchase must have been made from an authorized retailer in the United States (including Puerto Rico) or Canada. The product must also be located in the country where it was purchased at the time of warranty service.

How to Get Service

Before obtaining warranty service, you may visit www.vizio.com for additional help and troubleshooting. To obtain warranty service, contact VIZIO Technical Support via email at TechSupport@VIZIO.com or via phone at 877 MY VIZIO (877-698-4946). The VIZIO Technical Support hours are 6:00AM to 9:00PM Monday through Friday and 7:00AM to 4:00PM Saturday and Sunday, Pacific Time.

Your Obligations Before Service

You must obtain pre-authorization before sending your product to a VIZIO service center. You may be required to supply a purchase receipt (or copy) to show that the product is within the warranty period.

When you return a product to a VIZIO service center, you must ship the product in its original packaging or in packaging that affords an equal degree of protection. VIZIO Technical Support will provide instructions for packing and shipping the product to the VIZIO service center.

ALL USER DATA AND DOWNLOADED APPLICATIONS STORED ON A PRODUCT WILL BE DELETED IN THE COURSE OF SOME IN-HOME AND ALL SHIP-IN WARRANTY SERVICE. If this occurs, your product will be restored to its original state. You will be responsible for restoring all applicable user data and downloaded applications. Recovery and reinstallation of user data and downloaded applications is not covered under this warranty. In order to protect your personal information, VIZIO recommends that you always clear all personal information from the product before it is serviced, regardless of the service.

VIZIO's Responsibilities

If VIZIO determines that a product is covered by this warranty, VIZIO will (at its option) repair or replace it, or refund the purchase price to you. There will be no charge for parts or labor during the warranty period. Replacement parts may be new or recertified at VIZIO's option and sole discretion. Replacement parts and VIZIO's labor are warranted for the remaining portion of the original warranty or for ninety (90) days from warranty service, whichever is longer.

Types of Service

Products must be sent to a VIZIO service center to obtain warranty service. VIZIO is not responsible for transportation costs to the service center, but VIZIO will cover return shipping to the customer.

What This Warranty Does Not Cover

This warranty does not cover: (a) cosmetic damage; (b) normal wear and tear; (c) improper operation; (d) improper voltage supply or power surges; (e) signal issues; (f) damage from shipping; (g) acts of God; (h) customer misuse, modifications or adjustments; (i) installation, set-up, or repairs attempted by anyone other than by a VIZIO authorized service center; (j) products with unreadable or removed serial numbers; (k) products requiring routine maintenance; or (l) products sold "AS IS", "CLEARANCE", "FACTORY RECERTIFIED", or by a non-authorized reseller.

What to Do If You Are Not Satisfied With Service

If you feel VIZIO has not met its obligations under this warranty, you may attempt to resolve the issue informally with VIZIO. If you are unable to resolve the issue informally and wish to file a formal claim against VIZIO, and if you are a resident of the United States, you must submit your claim to binding arbitration according to the procedures described below, unless an exception applies. Submitting a claim to binding arbitration means that you do not have the right to have your claim heard by a judge or jury. Instead your claim will be heard by a neutral arbitrator.

Binding Arbitration Agreement: Class Action Waiver (U.S. Residents Only)

UNLESS YOU HAVE BROUGHT AN ELIGIBLE CLAIM IN SMALL CLAIMS COURT OR HAVE OPTED OUT AS DESCRIBED BELOW, ANY CONTROVERSY OR CLAIM RELATING IN ANY WAY TO YOUR VIZIO PRODUCT, INCLUDING ANY CONTROVERSY OR CLAIM ARISING OUT OF OR RELATING TO THIS WARRANTY, A BREACH OF THIS WARRANTY, OR THE VIZIO PRODUCT'S SALE, CONDITION OR PERFORMANCE, WILL BE SETTLED BY BINDING ARBITRATION ADMINISTERED BY THE AMERICAN ARBITRATION ASSOCIATION AND CONDUCTED BY A SINGLE ARBITRATOR APPOINTED BY THE AMERICAN ARBITRATION ASSOCIATION, IN ACCORDANCE WITH ITS COMMERCIAL ARBITRATION RULES AND ITS SUPPLEMENTARY PROCEDURES FOR CONSUMER-RELATED DISPUTES. You may learn more about the American Arbitration Association and its rules for arbitration by visiting www.adr.org or by calling 800-778-7879. Since this warranty concerns a transaction in interstate or international commerce, the Federal Arbitration Act will apply.

The filing fees to begin and carry out arbitration will be shared between you and VIZIO, but in no event will your fees ever exceed the amount allowable by the American Arbitration Association, at which point VIZIO will cover all additional administrative fees and expenses. VIZIO waives its right to recover attorneys' fees in connection with any arbitration under this warranty. If you are the prevailing party in an arbitration to which the Supplementary Procedures for Consumer-Related Disputes applies, then you are entitled to recover attorneys' fees as the arbitrator may determine. The dispute will be governed by the laws of the state or territory in which you resided at the time of your purchase (if in the United States). The place of arbitration will be Irvine, California, or your county of residence (if in the United States). The arbitrator will have no authority to award punitive or other damages not measured by the prevailing party's actual damages, except as may be required by statute. The arbitrator will not award consequential damages, and any award will be limited to monetary damages and will include no equitable relief, injunction, or direction to any party other than the direction to pay a monetary amount. Judgment on the award rendered by the arbitrator will be binding and final, except for any right of appeal provided by the Federal Arbitration Act, and may be entered in any court having jurisdiction. Except as may be required by law, neither you nor VIZIO nor an arbitrator may disclose the existence, content, or results of any arbitration under this warranty without the prior written consent of you and VIZIO.

ANY DISPUTE, WHETHER IN ARBITRATION, IN COURT, OR OTHERWISE, WILL BE CONDUCTED SOLELY ON AN INDIVIDUAL BASIS. VIZIO AND YOU AGREE THAT NO PARTY WILL HAVE THE RIGHT OR AUTHORITY FOR ANY DISPUTE TO BE ARBITRATED AS A CLASS ACTION, A PRIVATE ATTORNEY GENERAL ACTION, OR IN ANY OTHER PROCEEDING IN WHICH EITHER PARTY ACTS OR PROPOSES TO ACT IN A REPRESENTATIVE CAPACITY.

NO ARBITRATION OR PROCEEDING WILL BE JOINED, CONSOLIDATED, OR COMBINED WITH ANOTHER ARBITRATION OR PROCEEDING WITHOUT THE PRIOR WRITTEN CONSENT OF ALL PARTIES TO ANY SUCH ARBITRATION OR PROCEEDING.

Exceptions to Binding Arbitration Agreement and Class Action Waiver

IF YOU DO NOT WISH TO BE BOUND BY THE BINDING ARBITRATION AGREEMENT AND CLASS ACTION WAIVER, THEN: (1) you must notify VIZIO in writing within sixty (60) days of the date that you purchased the product; (2) your written notification must be mailed to VIZIO at 39 Tesla, Irvine, CA 92618, Attn: Legal Department; and (3) your written notification must include (a) your name, (b) your address, (c) the date you purchased the product, and (d) a clear statement that you wish to opt out of the binding arbitration agreement and class action waiver.

In addition, you may pursue a claim in small claims court in your county of residence (if in the United States) or in Orange County, California. In such case the provisions of the section titled "Binding Arbitration Agreement; Class Action Waiver (U.S. Residents)" will not apply.

Exclusions and Limitations

TO THE GREATEST EXTENT PERMITTED BY APPLICABLE LAW, THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE DESCRIBED ABOVE. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WILL BE LIMITED IN DURATION TO THE WARRANTY PERIOD SET FORTH ABOVE. SOME STATES AND PROVINCES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

VIZIO WILL NOT BE RESPONSIBLE FOR LOSS OF USE, LOSS OF INFORMATION OR DATA, COMMERCIAL LOSS, LOST REVENUE OR LOST PROFITS, OR OTHER INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EVEN IF VIZIO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND EVEN IF THE REMEDY FAILS OF ITS ESSENTIAL PURPOSE. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

IN LIEU OF ANY OTHER REMEDY FOR ANY AND ALL LOSSES AND DAMAGES RESULTING FROM ANY CAUSE WHATSOEVER (INCLUDING VIZIO'S NEGLIGENCE, ALLEGED DAMAGE, OR DEFECTIVE GOODS, NO MATTER WHETHER SUCH DEFECTS ARE DISCOVERABLE OR LATENT), VIZIO MAY, AT ITS SOLE AND EXCLUSIVE OPTION AND IN ITS DISCRETION, REPAIR OR REPLACE YOUR PRODUCT, OR REFUND ITS PURCHASE PRICE. AS NOTED, SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

How the Law Applies

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state and province to province. This warranty applies to the greatest extent permitted by applicable law.

General

No employee or agent of VIZIO may modify this warranty. If any term of this warranty, other than the class action waiver, is found to be unenforceable, that term will be severed from this warranty and all other terms will remain in effect. If the class action waiver is found to be unenforceable, then the entire section titled "Binding Arbitration Agreement; Class Action Waiver (U.S. Residents Only)" will not apply. This warranty applies to the maximum extent not prohibited by law.

Changes to Warranty

This warranty may change without notice, but any change will not affect your original warranty. Check www.vizio.com for the most current version.

Specifications

SP50-D5

Speaker Configuration
Four 1.5" Full Range Drivers
One 3.5" Subwoofer (sealed)

Inputs:
One USB (Supports .WAV format only)
802.11n (Wireless)
Ethernet (RJ45)
Bluetooth (BLE 4.1 Low Energy)

Sound Pressure Level
(Speaker): 95 dB

Frequency Response
(Speaker): 50 Hz - 20 KHz

Voltage: 120 VAC, 60 Hz

Operating Temperature: 41°F to 95°F (5°C to 35°C)

Compliances: UL, FCC Class B

LEGAL & COMPLIANCE

FCC Class B Radio Interference Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.
3. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference.

RF Exposure Information

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. This device complies with FCC radiation exposure limits set forth for an uncontrolled environment.

IC Statement

1. This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
 - (1) this device may not cause interference, and
 - (2) this device must accept any interference, including interference that may cause undesired operation of the device.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC Radiation Exposure Statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Battery Disposal and Recycling

You must dispose of this product properly, according to local laws and regulations. Because this product contains electronic components and/ or a battery, it must be disposed of separately from household waste. Contact local authorities to learn about disposal and recycling options. For more information, visit www.vizio.com/environment.

Software Licenses

All software is provided subject to software license agreements and you agree that you will be bound by such license agreements in addition to other applicable terms of use. By using the VIZIO products, you agree to the VIZIO Terms of Service and Privacy Policy, as well as Google's Terms of Service and Privacy Policy. The VIZIO Terms of Use and Privacy Policy may be updated from time to time and are available to view at <http://www.vizio.com/terms> and <http://www.vizio.com/privacy>, respectively.

Export Regulations

Customer acknowledges that the VIZIO products, which include technology and software, are subject to customs and export control laws in the United States ("US"). The products may also be subject to the customs and export control laws and regulations of the country in which the products are manufactured and/or received.

Internet Connectivity

Network conditions, environmental and other factors may negatively affect connectivity and the resulting audio quality, if any.

The applications and content of the applications pictured herein or described in accompanying documentation may only be available in certain countries or languages, may require additional fees or subscription charges, and may be subject to future updates, modifications or discontinuation without notice. VIZIO has no control over third party applications or content and assumes no responsibility for the availability or interruption of such applications or content. Additional third party terms, conditions and restrictions apply. A Google account is required to download applications from the Google Play store. A MyVIZIO account is required to access certain features of the VIZIO SmartCast app. Information in this Quick Start Guide is subject to change without notice. To review the most updated version of this Quick Start Guide and the associated User Manual, go to <http://www.vizio.com>.

© 2016 VIZIO, Inc. All Right Reserved.
Image(s) used under license from Shutterstock.com

This Quick Start Guide may not be copied in whole or in part without the written permission of VIZIO, Inc. VIZIO, Inc. has made reasonable efforts to ensure the accuracy of the information provided herein. All product specifications, functionality, features, configurations, performance, design and other product information described herein are subject to change without notice. VIZIO, Inc. is not responsible for typographical, technical, or descriptive errors.

VIZIO, the VIZIO logo, the V logo, and other terms and phrases are trademarks or registered trademarks of VIZIO, Inc.

HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. Used under license.

© 2016 Google Inc. All rights reserved. Android, Google Play, Google Cast and other marks are trademarks of Google inc.
Sound pressure level measured using pink noise at 1 meter, c-weighted.

Minimum requirements: Android 4.0 or later (to use the bluetooth functionality you must have Android™ 5.1 or later) iOS 8.0 or later. Subject to change. For a list of Android™ supported devices see [HTTPS://support.google.com/googleplay/answer/1727131?hl=en](https://support.google.com/googleplay/answer/1727131?hl=en) Article. iOS devices supported: iPhone, iPad.



For DTS patents, see <http://patents.dts.com>. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS TruVolume is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.



For DTS patents, see <http://patents.dts.com>. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS Studio Sound is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.



© 2016 VIZIO INC. ALL RIGHTS RESERVED.
160630AD-US-NC